

Liquid Crystal Room Thermometer

How to Read

- Remove backing liner, adhere to switch plate.
- Green number indicates the correct temperature. If green does not appear, temperature is between blue and tan numbers.
- Blue 62 indicates a temperature of 62 or lower; Red 84 indicates a temperature of 84 or greater.

Precautions

- Keep out of direct sun light
- Position on interior wall for most accurate reading

IFU007REV0

IFU007REV0